
ALARM & EVENTS FROM SCADA/DCS/PLC USING VIRTUAL PRINTER




To get Alarms and Events from SCADA InTouch HMI, First create Virtual Printer


Search, Write Device and Printers, Click on Devices and Printers.



Click on Add a printer




Click on The printer that I want isn't listed, As Shown below.




Choose a device or printer to add to this PC


Select a device



Select Add a printer using a TCP/IP address or hostname and Click on Next



Write Hostname or IP Address where to print the alarm and Events from SCADA/DCS/PLC ,After that **Click on Next.**




After Clicking on Next below Screen appear,




Detecting TCP/IP port

Detecting the TCP/IP port... Windows will automatically move to the next page when the detection is done.






Select Custom and Click on Settings



Now, In Raw Settings Write Port Number and Click on OK



Click on Next





Additional port information required

The device is not found on the network. Be sure that:


- 1. The device is turned on.
- 2. The network is connected.
- 3. The device is properly configured.
- 4. The address on the previous page is correct.

If you think the address is not correct, click Back to return to the previous page. Then correct the address and perform another search on the network. If you are sure the address is correct, select the device type below.







Below Screen Appear after click on Next



Select Generic and Generic/Text only as Shown Below. After that Click on Next.




Select Replace the current Driver and Click on Next



Write Printer Name and Click on Next.

←	Add Printer Type a printer name		
	Printer name:	SCADA_ALM	
	This printer will be installed with the Generic / Text Only driver.		
		Next Cancel	
Sele	ect do not share	chis printer and Click on Next.	
\leftarrow	🖶 Add Printer		
	Printer Sharing		
	If you want to share this printer, you must provide a share name. You can use the suggested name or type a new one. The share name will be visible to other network users.		
	Do not share this p	Do not share this printer	
	O Share this printer so that others on your network can find and use it		
	Share name:		
	Location:		
	Comment:		
		Next Cancel	


To check printer working properly or not Click on Print a Test page.



Cancel


Finish

After Successful Testing of Test page Click on Close







Click on Finish




After Clicking on Finish Virtual Printer SCADA_ALM Appear As shown below.




To create new Channel, In X-Force Alarm Web Configuration. Login with credential (User Name and Password)




Click on Configuration, Expand configuration click on channel configuration and right click on it and select ADD channel.




Add Details like communication type (Network Communication), Channel name, Plant Name, Set Default Color Then click on save




As Shown Below write local IP, Remote IP, Backup IP, Port No, Select Terminator 1 and 2, Set Minimum Length Data accordingly. And click on save.



Channel is Appear here as shown below.




Now Open X-Force Capture Process and Restore it.






After Restore X-Force Capture Process, SCADA_ALM Channel appear, Check Port No, local IP,Remote IP and Backup IP connected or not.

(On Channel SCADA_ALM, Printer Test page Appear)




Now to start Alarms from SCADA AVEVA InTouch HMI,


Open InTouch HMI Application Manager,




Double click on Test_alm




As Shown Below InTouch WindowMaker >> Expand Application




After Expand of Applications Double click on Alarm Printer.




Click on Configure




In Printing, Select Printer and Browse Printer




Select Virtual Printer Which already Created.(SCADA_ALM) and Click on OK




Click on Apply and then Click on OK




Click on Enable/Disable button printing




Click on Start/Stop as Shown Below




After Clicking on Start, Printer Name Appear here as shown below.




Now, Click on RUNTIME




Start the alarms (Do Not Closed WindowViewer)



Restore the X - Force Capture Process Application and Check Alarms are Coming or not.



Now Check Capture file Created or not.



Restore the X - Force DataLink Application and Click on channel **SCADA_ALM** Check Alarms are Coming or not.

