

Safety

Pollution degree	2
Installation category	III

Isolation

High Voltage Test	1) 3.7kV RMS 50Hz for 1 minute between all electrical circuits 2) 2.2kV RMS 50Hz for 1 minute between RS485 input and all electrical circuits.
-------------------	---

Environmental conditions

Operating temperature	0 to 50°C
Storage temperature	-25 to +70°C
Relative humidity	0 .. 90 % RH (Non condensing)
Warm up time	3 minute (minimum)
Shock	15g in 3 planes
Vibration	10 .. 55 Hz, 0.15mm amplitude

Enclosure

Enclosure front	IP 50
Enclosure front with seal (optional)	IP 65
Enclosure back	IP 20

Dimensions

Bezel Size	96mm x 96mm DIN 43718
Panel cut out	92 ^{+0.8} mm X 92 ^{+0.8} mm
Overall Depth	55 mm
Panel thickness	1 - 3mm for self clicking 1 - 6mm for swivel screws
Weight	320 grams Approx.

Pulse output Option :

Relay	1NO + 1NC
Switching Voltage & Current	240VDC , 5Amp.
Default Pulse rate Divisor	1 per Wh (up to 3600W), 1 per kWh (up to 3600kW), 1 per MWh (above 3600 kW)
Pulse rate Divisors	Programmable on site
10	1 per 10Wh (up to 3600W), 1 per 10kWh (up to 3600kW), 1 per 10MWh (above 3600 kW)
100	1 per 100Wh (up to 3600W), 1 per 100kWh (up to 3600kW), 1 per 100MWh (above 3600 kW)
1000	1 per 1000Wh (up to 3600W), 1 per 1000kWh (up to 3600kW), 1 per 1000MWh (above 3600 kW)
Pulse Duration	60ms , 100ms or 200ms

Note : Above conditions are also applicable for Reactive & Apparent Energy .


ModBus (RS 485) Option :

Protocol	ModBus (RS 485)
Baud Rate	19200 , 9600 , 4800 or 2400 (Programmable)
Parity	Odd or Even, with 1 stop bit, Or None with 1 or 2 stop bits


15. Connection for Optional Pulse Output / RS 485

(rear view of Delta Energy) :


1. Pulse Output (Limit Output)



2. RS 485 Output



3. Pulse (Limit) + RS 485 Output



The Information contained in these installation instructions is for use only by installers trained to make electrical power installations and is intended to describe the correct method of installation for this product. However, 'Rishabh Instruments' has no control over the field conditions which influence product installation. It is the user's responsibility to determine the suitability of the installation method in the user's field conditions. 'Rishabh Instruments' only obligations are those in 'Rishabh Instruments' standard Conditions of Sale for this product and in no case will 'Rishabh Instruments' be liable for any other incidental, indirect or consequential damages arising from the use or misuse of the products.

Delta ENERGY

DELTA ENERGY- DIGITAL MULTIFUNCTION INSTRUMENT

Programmable Multi-function Digital Panel Meter Installation & Operating Instructions

Section	Contents
1.	Introduction
2.	Measurement Reading Screens
3.	Programming
3.1	Password Protection
3.2	Menu selection
3.2.1	System Parameter selection screen
3.2.1.1	System type
3.2.1.2	Potential transformer Primary value
3.2.1.3	Potential transformer secondary value
3.2.1.4	Current transformer Primary value
3.2.1.5	Current transformer Secondary value
3.2.1.6	Demand integration time
3.2.1.7	Auto Scrolling
3.2.1.8	No. of Poles Selection
3.2.2	Communication Parameter selection screen
3.2.2.1	Address Setting
3.2.2.2	RS 485 Baud rate
3.2.2.3	RS 485 Parity selection
3.2.3	Reset Parameter selection screen
3.2.3.1	Resetting Parameter
3.2.4	Output Option selection screen (menu)
3.2.4.1	Configuration of Output
3.2.4.1.1	Relay output selection menu
3.2.4.1.1.1	Pulse output
3.2.4.1.1.1.1	Assignment of Energy to Pulse
3.2.4.1.1.1.2	Pulse Duration Selection
3.2.4.1.1.1.3	Pulse Rate
3.2.4.1.1.2	Limit output
3.2.4.1.1.2.1	Assignment of Limit Output to Parameter
3.2.4.1.1.2.2	Limit Configuration
3.2.4.1.1.2.3	Trip point selection
3.2.4.1.1.2.4	Hysteresis selection
3.2.4.1.1.2.5	Energizing delay time
3.2.4.1.1.2.6	De-energizing delay time
3.2.5	Quit screen
4.	Run - Hour
5.	On - Hour
6.	Number of Interruption
7.	Negative Sign Indication
8.	Relay Output
8.1	Pulse output
8.2	Limit Switch
9.	RS 485 (ModBus)
9.1	User Assignable Modbus Register
10.	Phaser Diagram
11.	Installation
11.1	EMC Installation Requirements
11.2	Case Dimensions and Panel Cut-out
11.3	Wiring
11.4	Auxiliary Supply
11.5	Fusing
11.6	Earth / Ground Connections
12.	Connection Diagrams
13.	Optional Pluggable Module
14.	Specification
15.	Connection for Optional Pulse output / RS 485

15000830_Rev.B - 11/2011


TABLE 1:

Measured Parameters	Units of measurement
System Voltage	Volts
System Current	Amps
Frequency	Hz
Voltage L1-N(4wire only)	Volts
Voltage L2-N(4wire only)	Volts
Voltage L3-N(4wire only)	Volts
Voltage L1-L2	Volts
Voltage L2-L3	Volts
Voltage L3-L1	Volts
Current L1	Amps
Current L2	Amps
Current L3	Amps
System Active Power	KW
Active Power L1	KW
Active Power L2	KW
Active Power L3	KW
System reactive Power	KVAr
Reactive Power L1	KVAr
Reactive Power L2	KVAr
Reactive Power L3	KVAr
System Apparent Power	KVA
Apparent Power L1	KVA
Apparent Power L2	KVA
Apparent Power L3	KVA
System phase angle	Degree
Phase angle L1	Degree
Phase angle L2	Degree
Phase angle L3	Degree
System power factor	—
Power factor L1	—
Power factor L2	—
Power factor L3	—
Active Import Energy (8 Digit resolution)	KWh
Active Export Energy (8 Digit resolution)	KWh
Reactive Import Energy (8 Digit resolution)	KVArh
Reactive Export Energy (8 Digit resolution)	KVArh
Apparent Energy (8 Digit resolution)	KVAh
RPM	RPM
Max. Value System Voltage	V
Max. Value System Current	A
Min. Value System Voltage	V
Min. Value System Current	A
Current Demand	Amps
KVA Demand	KVA
KW Import Demand	KW
KW Export Demand	KW
Max. Current Demand	Amps
Max. kVA Demand	KVA
Max. KW Import Demand	KW
Max. KW Export Demand	KW
Run Hours	Hours
ON Hours	Hours
No. of Auxiliary Interruptions	Counts

1. Introduction

The Delta Energy is a panel mounted 96 x 96mm DIN Quadratic Digital Panel Meter, which measures important electrical parameters in 3 ph 4 wire / 3 wire / 1ph Network and replaces the multiple analog panel meters. It measures electrical parameters like AC voltage, Current, Frequency, Power, Energy(Active / Reactive / Apparent), phase angle, power factor & many more.

The instrument integrates accurate measurement technology (All Voltages & current measurements are True RMS upto 15th Harmonic) with 3 line 4 digits Ultra high bright LED display with Clearly visible Annunciated units with bright LED from Back side.



1 2 3 4

The Delta energy can be configured and Programmed on site for the following : PT Primary, PT Secondary, CT Primary, CT Secondary (5A or 1A) and System Type 3 phase 3W or 4W or single phase system.

The front panel has four push buttons for user interface to scroll through the available parameters. These four keys has function as follow :

1. V/A : Selects & Scrolls through Voltage parameters display and phase current parameters display.
2. P : Select & Scrolls phase & system Power parameters : Active power, apparent power, reactive power, phase angle, power factor, then system Apparent, Reactive, Active Power, Phase angle, Power factor, then Current demand, KVA demand, Max current demand, Max KVA demand, Active import demand, Max active import demand, Active export demand, Max active export demand and then back to Phase active power.

3. E : Select & Scrolls through Energy parameters : Active energy (Import), Active energy (Export), Reactive energy (Import), Reactive energy (Export), Apparent energy and then back to Active energy (import).

4. Sys : Select & Scroll through System parameters : Voltage-Current-Frequency, Hi values of system voltage and current, Lo values of system Voltage and current, RPM, run Hour, ON hour and no. of interruptions and back to System Voltage-Current Frequency screen


The Delta energy come with 14mm display and units annunciated from back side, which enables to take reading from long distance. The problem with conventional LED annunciators is overcome with the Delta Energy.

2. Measurement Reading Screens


In normal operation the user is presented with the measurement reading screens. These screens may be scrolled through one at a time by pressing the "V/A" key for Voltages and Currents, "P" key for phase, active Reactive & apparent power, System Apparent, reactive & Active powers and all demand parameters. "E" key for Active energy (Import), Active energy (Export), Reactive energy (Import), reactive energy (Export) and Apparent energy, "Sys" key for System Voltage-Current -Frequency, max. and min. Values of system Voltage and Current, RPM, Run hours, ON hours, No. of Aux interruptions.

a. "V/A" Key:

Screen 1 : Voltage Line to Neutral
(For 3Ph4 Wire only)



Screen 2 : Voltage Line to Line
(For 3Ph 4Wire & 3 Wire)




Screen 3 : Line Currents



b. "P" Key:


Screen 1 : Phase Active power
(For 3Phase 4 wire only)



Screen 2 : Phase Apparent power
(For 3Phase 4 wire only)




Screen 3 : Phase Reactive power
(For 3Phase 4 wire only)




Screen 4 : Phase Angle
(For 3Phase 4 wire only)




Screen 5 : Phase power factor
(For 3Phase 4 wire only)




Screen 6 : System powers
(Apparent, reactive, active)




Screen 8 : Current Demand/
kVA Demand



Screen 10 : Import kW Demand




Screen 12 : Export kW Demand




c. "E" Key:


Screen 1 : Active Energy(Import)




Screen 7 : System Phase Angle
& power factor (3P4W &3W)




Screen 9 : Max Current Demand/
Max kVA Demand




Screen 11 : Max Import kW
Demand




Screen 13 : Max Export kW
Demand



Screen 2 : Active Energy (Export)



13. Optional Pluggable Module



14. Specification :

System

3 Phase 3 Wire / 4 Wire or Single Phase programmable at site

Inputs

Nominal Input Voltage	500 V _{LL} (290V _{LN}) AC RMS
System PT Primary Values	100V _{LL} to 692 kV _{LL} , programmable at site
System PT Secondary Values	100V _{LL} to 500 V _{LL} , programmable at site
Max continuous input voltage	120% of Rated Value
Nominal input voltage burden	0.3VA approx. per Phase (for ext. Aux. Meter)
Nominal Input Current	5A / 1A AC RMS
Max continuous input current	120% of Rated Value
Nominal input current burden	<0.2VA approx. per phase
System CT primary values	Std. Values 1 to 9999A (1 or 5 Amp secondary)
System Secondary Values	1A / 5A, programmable at site

Overload withstand

Voltage input	2 x Rated Value (1s application repeated 10 times at 10s intervals)
Current input	20 x Rated Value (1s application repeated 5 times at 5 min. intervals)

Auxiliary Supply

External Auxiliary Supply	40V to 300V AC/DC (+/- 5% Approx.)
Self Powered	Input Voltage Range from 80% to 100% of rated value (Self Powered meter is available only in 3 Phase 4W and 1 phase network. Aux input is derived from L1 phase)
Frequency Range	45 to 65 Hz
VA Burden	4 VA Approx.

Operating Measuring Ranges

Voltage with external Aux.	10 ... 120 % of Rated Value
Voltage with Self Aux.	80 ... 120% of Rated Value
Current	10 ... 120 % of Rated Value
Frequency	45 .. 65 Hz
Power Factor	0.5 Lead ... 1 .. 0.5 Lag

Reference conditions for Accuracy :

Reference temperature	23°C ± 2°C
Input frequency	50 or 60Hz ± 2%
Input waveform	Sinusoidal (distortion factor 0.005)
Auxiliary supply voltage	Rated Value ± 1 %
Auxiliary supply frequency	Rated Value ± 1 %
Voltage Range	20 ... 100% of Nominal Value
Current Range	10 ... 100% of Nominal Value
Power / Energy	cosφ / sinφ=1 for Active / Reactive Power & Energy 10 ... 100% of Nominal Current & 20 ... 100% of Nominal Voltage. 40 ... 100% of Nominal Current & 20 ... 100% of Nominal Voltage
Power Factor / Phase Angle	

Accuracy

Voltage	± 1.0 % of Nominal Value
Current	± 1.0 % of Nominal Value
Frequency	± 0.15% of mid frequency
Active power	± 1.0 % of Nominal Value
Reactive power	± 1.0 % of Nominal Value
Apparent Power	± 1.0 % of Nominal Value
Power factor	± 2.0 % of unity
Phase angle	± 2.0 % of range
Active energy	± 1.0 % of range
Reactive energy	± 1.0 % of range
Apparent energy	± 1.0 % of range

Influence of variations

Temperature Coefficient	0.05% /°C for Current (10..120% of Rated Value) (For Rated value range of use 0... 50°C) 0.025% /°C for Voltage (10..120% of Rated Value)
Error change due to variation of an influence quantity	2 * Error allowed for the reference condition applied in the test.

Display

LED	3 line 4 digits, Display height : 14mm
Annunciation of units	Bright LED s from Back side of screen
Update rate	Approx. 4 seconds


Controls

User Interface	4 push buttons
----------------	----------------


Standards

EMC Immunity	IEC 61326-1 : 2005
EMC Emmission	IEC 61326-1 : 2005
Safety	IEC 61010-1-2001, permanently connected use
IP for water & dust	IEC 60529





11.2 Case Dimension and Panel Cut Out



With optional MODBUS / Limit switch.




12. Connection Diagrams




*Note: For Measurement of parameters, Voltage must be present between terminal 2 & 11 (i.e. phase L1) for single phase or 3 phase 4 wire network and between terminal 2 & 5 (i.e. phase L1-L2) or 2 & 8 (i.e. phase L3-L1) for 3 phase 3 wire network.


Screen 3 : Reactive Energy(Import)




Screen 4 : Reactive Energy(Export)




Screen 4 : RPM Measurement




Screen 5 : Run Hours




Screen 5 : Apparent Energy




Screen 1 : System Values (Voltage, Current, Frequency)




Screen 6 : ON Hours




Screen 7 : No. of Interruptions



Screen 2 : Max. Values



Screen 3 : Min. Values



11.3 Wiring

Input connections are made directly to screw-type terminals with indirect wire pressure. Numbering is clearly marked on the connector. Choice of cable should meet local regulations. Terminal for both Current and Voltage inputs will accept upto 4mm² (12AWG) solid or 2.5 mm² stranded cable.

Note : It is recommended to use wire with lug for connection with meter.

11.4 Auxiliary Supply


Delta Energy should ideally be powered from a dedicated supply, however powered from the signal source, provided the source remains within it may be the limits of the Chosen auxiliary voltage range.

11.5 Fusing

It is recommended that all voltage lines are fitted with 1 amp HRC fuse.

11.6 Earth/Ground Connections

For safety reasons, CT secondary connections should be grounded in accordance with local regulations.



"P" : "P" KEY
"V/A" : "V/A" KEY

3. Programming


The following sections comprise step by step procedures for configuring the Delta Energy for individual user requirements.

To access the set-up screens press and hold the "V/A" and "P" key simultaneously for 5 seconds. This will take the User into the Password Protection Entry Stage (Section 3.1).

3.1. Password Protection

Password protection can be enabled to prevent unauthorised access to set-up screens, by default password protection is not enabled.

Password protection is enabled by selecting a four digit number other than 0000, setting a password of 0000 disables the password protection.




Enter Password, prompt for first digit.
(* Denotes that decimal point will be flashing).

Press the "V/A" key to scroll the value of first digit from 0 through to 9, the value will wrap from 9 round to 0.

Press the "P" key to advance to next digit.


In special case where the Password is "0000" pressing the "P" key when prompted for the first digit will advance to "Password confirmed" screen.



Password confirmed.

Pressing "V/A" key will advance to the "New / change Password" entry stage.

Pressing the "P" key will advance to the Menu selection screen. (See section 3.2).




Password Incorrect.

The unit has not accepted the Password entered.

Pressing the "V/A" key will return to the Enter Password stage.


Pressing the "P" key exits the Password menu and returns operation to the measurement reading mode.



Enter Password, first digit entered, prompt for second digit.
(* Denotes that decimal point will be flashing).

Use the "V/A" key to scroll the value of the second Digit from 0 through to 9, the value will wrap from 9 round to 0.

Press the "P" key to advance to next digit.




New / Change Password

(*Decimal point indicates that this will be flashing).

Pressing the "V/A" key will scroll the value of the first digit from 0 through to 9, the value will wrap from 9 round to 0.


Pressing the "P" key to advance the operation to the next digit and sets the first digit, in this case to "2"



Enter Password, second digit entered, prompt for third digit.
(* Denotes that decimal point will be flashing).

Use the "V/A" key to scroll the value of the third digit from 0 through to 9, the value will wrap from 9 round to 0.


Press the "P" key to advance to next digit.



New / Change Password, first digit entered, prompting for second digit. (*Decimal point indicates that this will be flashing).

Pressing the "V/A" key will scroll the value of the second digit from 0 through to 9, the value will wrap from 9 round to 0.


Pressing the "P" key to advance the operation to the next digit and sets the second digit, in this case to "1"



Enter Password, third digit entered, prompt for fourth digit.
(* Denotes that decimal point will be flashing).

Use the "V/A" key to scroll the value of the fourth digit from 0 through to 9, the value will wrap from 9 round to 0.


Press the "P" key to advance to verification of the password.




New / Change Password, second digit entered, prompting for third digit. (*decimal point indicates that this will be flashing).

Pressing the "V/A" key will scroll the value of the third digit from 0 through to 9, the value will wrap from 9 round to 0.

Pressing the "P" key to advance the operation to the next digit and sets the third digit, in this case to "5"



Enter Password, fourth digit entered, awaiting verification of the password.



New / Change Password, third digit entered, prompting for fourth digit. (* denotes that decimal point will be flashing).

Pressing the "V/A" key will scroll the value of the fourth digit from 0 through to 9, the value will wrap from 9 round to 0.

Pressing the "P" key to advance the operation to the "New Password Confirmed" and sets the fourth digit, in this case to "3".

Response : (Volt2 = 219.30 / Power Factor1 = 1.0)

Device Address	01 (Hex)
Function Code	04 (Hex)
Byte count	08 (Hex)
Data Register-1 High Byte	43 (Hex)
Data Register-1 Low Byte	5B (Hex)
Data Register-2 High Byte	4E (Hex)
Data Register-2 Low Byte	04 (Hex)
Data Register-3 High Byte	3F (Hex)
Data Register-3 Low Byte	80 (Hex)
Data Register-4 High Byte	00 (Hex)
Data Register-4 Low Byte	00 (Hex)
CRC Low	79 (Hex)
CRC High	3F (Hex)

Voltage 2 Data

Power Factor 1Data


User Assignable mapping Registers (Starting Address) (4X Registers Table 10)		User Assignable Data Registers (Starting Address) (3X Registers Table 9)	
0x200 Voltage 2 (0x0002)	→	0x200 (16 bit)	0x201 (16 bit)
0x201 Power Factor 1 (0x001E)	→	0x202 (16 bit)	0x203 (16 bit)
0x202 Wh Import (0x0048)	→	0x204 (16 bit)	0x205 (16 bit)
0x203 Frequency (0x0046)	→	0x206 (16 bit)	0x207 (16 bit)
...	
0x212 Current 1 (0x0006)	→	0x224 (16 bit)	0x225 (16 bit)
0x213 VAh (0x0050)	→	0x226 (16 bit)	0x227 (16 bit)

To get the data through User assignable Register use following steps:

- Assign starting addresses (Table 3) of parameters of interest to a "User assignable mapping registers" in a sequence in which they are to be accessed (see section "Assigning parameter to user assignable registers")
- Once the parameters are mapped data can be acquired by using "User assignable data register" Starting address. i.e. to access data of Voltage2, Power factor1, Wh import, Frequency send query with starting address 0x200 with number of register 8 or individually parameters can be accessed for example if current1 to be accessed use starting address 0x212. (See section Reading Parameter data through User Assignable Registers)

10. Phasor Diagram :

Quadrant 1: 0° to 90°
Quadrant 2: 90° to 180°
Quadrant 3: 180° to 270°
Quadrant 4: 270° to 360°



Connections	Quadrant	Sign of Active Power (P)	Sign of Reactive Power (Q)	Sign of Power Factor (PF)	Inductive / Capacitive
Import	1	+ P	+ Q	+	L
Import	4	+ P	- Q	+	C
Export	2	- P	+ Q	-	C
Export	3	- P	- Q	-	L


Inductive means Current lags Voltage
Capacitive means Current leads Voltage

When Delta Energy displays Active power (P) with " + " (positive sign) , the connection is " Import " .

When Delta Energy displays Active power (P) with " - " (negative sign) , the connection is " Export " .

11. Installation

Mounting of Delta Energy is featured with easy "Clip- in" mounting. Push the meter in panel slot (size 92 x92 mm), it will click fit into panel with the four integral retention clips on two sides of meter. If required Additional support is provided with swivel screws as shown in figure.



The front of the enclosure conforms to IP50. Additional protection to the panel may be obtained by the use of an Optional panel gasket. The terminals at the rear of the product should be protected from liquids.

The Delta Energy should be mounted in a reasonably stable ambient temperature and where the operating temperature is within the range 0 to 50°C. Vibration should be kept to a minimum and the product should not be mounted where it will be subjected to excessive direct sunlight.

Caution

- In the interest of safety and functionality this product must be installed by a qualified engineer, abiding by any local regulations.
- Voltages dangerous to human life are present at some of the terminal connections of this unit. Ensure that all supplies are de-energised before attempting any connection or disconnection.
- These products do not have internal fuses therefore external fuses must be used to ensure safety under fault conditions.

11.1 EMC Installation Requirements

This product has been designed to meet the certification of the EU directives when installed to a good code of practice for EMC in industrial environments, e.g.

- Screened output and low signal input leads or have provision for fitting RF suppression components, such as ferrite absorbers, line filters etc., in the event that RF fields cause problems.

Note: It is good practice to install sensitive electronic instruments that are performing critical functions, in EMC enclosures that protect against electrical interference which could cause a disturbance in function.

- Avoid routing leads alongside cables and products that are, or could be, a source of interference.

- To protect the product against permanent damage, surge transients must be limited to 2kV pk. It is good EMC practice to suppress differential surges to 2kV at the source. The unit has been designed to automatically recover in the event of a high level of transients. In extreme circumstances it may be necessary to temporarily disconnect the auxiliary supply for a period of greater than 5 seconds to restore correct operation.

The Current inputs of these products are designed for connection in to systems via Current Transformers only, where one side is grounded.

- ESD precautions must be taken at all times when handling this product.

Table 4 : Continued...

Address (Register)	Parameter No.	Parameter	Modbus Start Address Hex		3P 4W	3P 3W	1PH
			High Byte	Low Byte			
30085	43	W Demand (Import)	00	54	✓	✓	✓
30087	44	W Max Demand (Import)	00	56	✓	✓	✓
30089	45	W Demand (Export)	00	58	✓	✓	✓
30091	46	W Max Demand (Export)	00	5A	✓	✓	✓
30101	51	VA Demand	00	64	✓	✓	✓
30103	52	VA Max Demand	00	66	✓	✓	✓
30105	53	A Demand	00	68	✓	✓	✓
30107	54	A Max Demand	00	6A	✓	✓	✓
30133	67	Volts Ave Max	00	84	✓	✓	✓
30135	68	Volts Ave Min	00	86	✓	✓	✓
30141	71	Current Ave Max	00	8C	✓	✓	✓
30143	72	Current Ave Min	00	8E	✓	✓	✓
30201	101	VL 1 - 2 (Calculated)	00	C8	✓	X	X
30203	102	VL 2 - 3 (Calculated)	00	CA	✓	X	X
30205	103	VL 3 - 1 (Calculated)	00	CC	✓	X	X
30227	114	Run Hour	00	E2	✓	✓	✓
30229	115	On Hour	00	E4	✓	✓	✓
30231	116	No. Of Interrupts	00	E6	✓	✓	✓

Note : Parameters 1,2,3 are L-N Voltage for 3P 4W & L-L Voltage for 3P 3W .

Accessing 4 X register for Reading & Writing :

Each setting is held in the 4X registers .ModBus code 03 is used to read the current setting and code 16 is used to write/change the setting. Refer Table 5 for 4 X Register addresses.

Example : Reading System type

System type : Start address= 0A (Hex) Number of registers = 02
 Note :Number of registers = Number of Parameters x 2

Query :

Device Address	01 (Hex)
Function Code	03 (Hex)
Start Address High	00 (Hex)
Start Address Low	0A (Hex)
Number of Registers Hi	00 (Hex)
Number of Registers Lo	02 (Hex)
CRC Low	E4 (Hex)
CRC High	09 (Hex)

Start Address High : Most significant 8 bits of starting address of the parameter requested.
 Start Address low :Least significant 8 bits of starting address of the parameter requested.
 Number of register Hi : Most significant 8 bits of Number of registers requested.
 Number of register Lo : Least significant 8 bits of Number of registers requested.
 (Note : Two consecutive 16 bit register represent one parameter.)

Response: System Type (3phase 4 wire = 3)

Device Address	01 (Hex)
Function Code	03 (Hex)
Byte Count	04 (Hex)
Data Register1 High Byte	40 (Hex)
Data Register1Low Byte	40 (Hex)
Data Register2 High Byte	00 (Hex)
Data Register2 Low Byte	00(Hex)
CRC Low	EE (Hex)
CRC High	27 (Hex)

Byte Count : Total number of data bytes received.

Data register 1 High Byte : Most significant 8 bits of Data register 1 of the parameter requested.
 Data register 1 Low Byte : Least significant 8 bits of Data register 1 of the parameter requested.
 Data register 2 High Byte : Most significant 8 bits of Data register 2 of the parameter requested.
 Data register 2 Low Byte : Least significant 8 bits of Data register 2 of the parameter requested.
 (Note : Two consecutive 16 bit register represent one parameter.)

Example : Writing System type

System type : Start address= 0A (Hex) Number of registers = 02

Query:(Change System type to 3phase 3wire = 2)

Device Address	01 (Hex)
Function Code	10 (Hex)
Starting Address Hi	00 (Hex)
Starting Address Lo	0A(Hex)
Number of Registers Hi	00 (Hex)
Number of Registers Lo	02(Hex)
Byte Count	04 (Hex)
Data Register-1High Byte	40 (Hex)
Data Register-1 Low Byte	00(Hex)
Data Register-2 High Byte	00(Hex)
Data Register-2 Low Byte	00(Hex)
CRC Low	66 (Hex)
CRC High	10 (Hex)

Byte Count : Total number of data bytes received.

Data register 1 High Byte : Most significant 8 bits of Data register 1 of the parameter requested.
 Data register 1 Low Byte : Least significant 8 bits of Data register 1 of the parameter requested.
 Data register 2 High Byte : Most significant 8 bits of Data register 2 of the parameter requested.
 Data register 2 Low Byte : Least significant 8 bits of Data register 2 of the parameter requested.

(Note : Two consecutive 16 bit register represent one parameter.)


Response:

Device Address	01 (Hex)
Function Code	10 (Hex)
Start Address High	00 (Hex)
Start Address Low	0A(Hex)
Number of Registers Hi	00 (Hex)
Number of Registers Lo	02(Hex)
CRC Low	61 (Hex)
CRC High	CA (Hex)

Start Address High : Most significant 8 bits of starting address of the parameter requested.
 Start Address low :Least significant 8 bits of starting address of the parameter requested.
 Number of register Hi : Most significant 8 bits of Number of registers requested.
 Number of register Lo : Least significant 8 bits of Number of registers requested.
 (Note : Two consecutive 16 bit register represent one parameter.)

3.2.1.8 No. of Poles Selection


This screen enables to set No. of poles of a Generator of which RPM is to be measured and to which the instrument is connected to monitor its parameters.



Selection of No. of poles of the Generator

Pressing "P" key accepts the present value and advance to System Parameter Selection. (See section 3.2.1)

Pressing the "V/A" key will enter the "No. of Poles selection" mode and scroll the number from 02 to 40 in step of 2. After 40 it scrolls the number again to 02.




No. of poles Confirmation

pressing the "V/A" key will re-enter the "No. of Poles Selection" mode.

Pressing "P" key set the number on screen as number of poles of generator and then it will jump back to the system parameter selection (See section 3.2.1)

3.2.2 Communication Parameter Selection :

3.2.2.1 Address Setting : This screen applies to the RS 485 output only. This screen allows the user to set RS485 parameter for instruments




The range of allowable address is 1 to 247 .

Enter Address, prompt for first digit.
 (* Denotes that decimal point will be flashing).

Press the "V/A" key to scroll the value of the first digit


Press the "P" key to advance to next digit.



Enter Address, first digit entered, prompt for second digit
 (* Denotes that decimal point will be flashing).


Use the "V/A" key to scroll the value of the second digit

Press the "P" key to advance to next digit.




Enter Address, second digit entered, prompt for third digit
 (* Denotes that decimal point will be flashing).

Use the "V/A" key to scroll the value of the third digit



Enter Address for third digit .

Press the "P" key to advance to Address confirmation Screen.




Address confirmation Screen.

This Screen confirms the Address set by user .

Press the "P" key to advance to next Screen
 "Rs485 Baud Rate" (See Section 3.2.2.2)

Pressing the "V/A" key will reenter the "Address Edit" mode.


3.2.2.2 RS 485 Baud Rate :



This screen allows the user to set Baud Rate of RS 485 port. The values displayed on screen are in kbaud ..

Pressing "P" key accepts the present value and advance to the Parity Selection (See Section 3.2.2.3)

Pressing the "V/A" key will enter the "Baud Rate Edit" mode and scroll the value through 2.4, 4.8, 9.6 , 19.2 and back to 2.4




RS 485 Baud Rate confirmation :

Pressing "V/A" key will be re-enter into the Baud Rate Edit mode

Pressing the "P" key will select the value and advances to the Parity Selection (See Section 3.2.2.3).

3.2.2.3 RS 485 Parity Selection :


This screen allows the user to set Parity & number of stop bits of RS 485 port.



Pressing "P" key accepts the present value and advance to Menu selection (see section 3.2).

Pressing the "V/A" key will enter the "Parity & stop bit Edit" mode and scroll the value through

odd : odd parity with one stop bit
no 1 : no parity with one stop bit
no 2 : no parity with two stop bit
E : even parity with one stop bit



RS 485 Parity confirmation :

Pressing "V/A" key will be re-enter into Parity Edit mode .


Pressing the "P" key will set the value.

Pressing the "P" key again will jump back to the communication parameter selection menu (see section 3.2.2).

3.2.3 Reset Parameter Selection :

3.2.3.1 Resetting Parameter

The following screens allow the users to reset the all Energy , Lo(Min), hi(Max),Demand,Run hour, . On hour, No.of Interrupts




Reset (None)

Pressing "P" key advances to Reset Parameter selection screen (see section 3.2.3)

Pressing the "V/A" key will enter the "Reset option" mode and scroll through Parameter and wrapping back to None.

3.2.4.1.1.2.1 Assignment of Limit output to parameter.


This screen is for Limit output mode selection. It allows the user to set Limit output corresponding measured value. Refer Table 2* Parameter for Limit output* for assignment.



Pressing "P" key accepts the present value and advance to the Limit configuration select screen. (see section 3.2.4.1.1.2.2).

Pressing the "V/A" key will enter the "Limit output Edit" mode and scroll the values, as per Table 2, *Parameter for Limit Output"

Pressing the "P" key advance to the Limit output confirmation screen.




Limit output Confirmation :

Pressing the "V/A" key will re-enter the "Limit output Edit"

Pressing the "P" key sets the displayed value and will advance to the Limit Configuration select screen (see section 3.2.4.1.1.2.2)

3.2.4.1.1.2.2 Limit Configuration select

This screen is used to set the Limit Configuration, four different types of configuration can be selected




- H i - E (High Alarm & Energized Relay)
 - H i - d (High Alarm & De-Energized Relay)
 - L o - E (Low Alarm & Energized Relay)
 - L o - d (Low Alarm & De-Energized Relay)
- (For detail refer to section 8.2)

Pressing the "P" key accepts the present value and advances to the "Trip point selection" screen (see section 3.2.4.1.1.2.3)

Pressing the "V/A" key will enter the Limit configuration edit mode and scroll through the Modes available.

Pressing the "P" key advances to the Limit configuration type confirmation menu.

Limit Configuration Confirmation



This screen will only appear following the edit of system type. If system type is to be changed again,


pressing the "V/A" key will return to the Limit configuration Type edit stage by blanking the bottom line of the display

Pressing the "P" key sets the displayed value and will advance to "Trip point selection" Screen (See section 3.2.4.1.1.2.3)

3.2.4.1.1.2.3 Trip point selection :

This screen applies to the Trip point selection.

This screen allows the user to set Trip point for instruments




The allowable range is 10% to 120% for High Alarm (refer table 2).
The allowable range is 10% to 100% for Low Alarm .

Enter value, prompt for first digit. (* Denotes that decimal point will be flashing).

Press the "V/A" key to scroll the values of the first digit.


Press the "P" key to advance to next digit.



The first digit entered, prompt for second digit (* Denotes that decimal point will be flashing).


Use the "V/A" key to scroll the value of the second digit.

Press the "P" key to advance to next digit.




The second digit entered, prompt for third digit (* Denotes that decimal point will be flashing).

Use the "V/A" key to scroll the value of the third digit.



Entered the value for third digit .

Press the "P" key to advance to trip point confirmation Screen.



Value confirmation Screen :

This Screen confirms the value set by user .


Press the "P" key to advance to next Screen

"Hysteresis selection" (see section 3.2.4.1.1.2.4).

Pressing the "V/A" key will return in edit mode.

3.2.4.1.1.2.4 Hysteresis selection :

This screen applies to the Hysteresis selection.



This screen allows the user to set Hysteresis for relay output


The allowable range is 0.5% to 50 % of Trip point .

Enter value, prompt for first digit. (* Denotes that decimal point will be flashing).

Press the "V/A" key to scroll the value of the first digit
Press the "P" key to advance to next digit.

Hysteresis for Frequency is calculated as % of trip point span from 40Hz. e.g. If trip point is 50%(55Hz) and hysteresis is set to 10%, then relay will reset at 53.5Hz [10% of (55 - 40Hz) 15Hz is 1.5Hz. Hence, 55 -1.5= 53.5Hz]


Note : In case of Io alarm if trip point is set at 100% then maximum 20% Hysteresis can be set.



The first digit entered, prompt for second digit (* Denotes that decimal point will be flashing).


Use the "V/A" key to scroll the value of the second digit

Press the "P" key to advance to next digit.




The second digit entered, prompt for third digit (* Denotes that decimal point will be flashing).

Use the "V/A" key to scroll the value of the third digit.



Entered value for third digit .

Press the "P" key to advance to Hysteresis confirmation Screen.




Hysteresis confirmation Screen :

This Screen confirms the percentage value set by user . & Screen will appear only after edit mode of Hysteresis.

Press the "P" key to advance to next Screen "Energizing delay time" (3.2.4.1.1.2.5).


3.2.4.1.1.2.5 Energizing Delay time.

This screen allows the user to set Energizing Delay time in seconds for Relay Limit Assigned Parameters .



Pressing "P" key accepts the present value and advance to De-energizing delay screen.

Pressing the "V/A" key will enter the "Energizing Delay" Edit mode and scroll the "Value" through 1 to 10.



Energizing delay time Confirmation :


This screen will appear only after edit mode of Energizing delay time.

Pressing the "V/A" key will re-enter the "Energizing delay Edit" mode.

Pressing "P" key set displayed value and will advance to Assignment of De-energizing delay time. (See section 3.2.4.1.1.2.6)


3.2.4.1.1.2.6 De-Energizing Delay time.

This screen allows the user to set De-Energizing Delay time in seconds for Relay Limit Assigned Parameters .



Pressing "P" key accepts the present value and advance to Configuration of output. (See section 3.2.4.1)

Pressing the "V/A" key will enter the "De-Energizing Delay" Edit mode and scroll the "Value" through 1 to 10.




De-Energizing delay time Confirmation :

This screen will appear only after edit mode of De-energizing delay time.

pressing the "V/A" key will re-enter the "De-energizing delay Edit" mode.


Pressing "P" key set displayed value and will advance to Configuration of output. (See section 3.2.4.1)

4. Run Hour




This Screen shows the total no. of hours the load is connected Even if the Auxiliary supply is interrupted count of Run hour will be maintained in internal memory & displayed in the format "hours. min". For example if Displayed count is 105000.10 r-H it indicates 105000 hours & 10 minutes. After 999999.59 run hours display will restart from zero. To reset run hour manually see section Resetting Parameter 3.2.3.1

5. On Hour



This Screen shows the total no. of hours the Axillary Supply is ON. Even if the Auxiliary supply is interrupted count of On hour will be maintained in internal memory & displayed in the format "hours. min". For example if Displayed count is 005000.10 On-H it indicates 005000 hours & 10 minutes. After 999999.59 On hours display will restart from zero. To reset On hour manually see section Resetting Parameter 3.2.3.1


6. Number of Interruption :



This Screen Displays the total no. of times the Axillary Supply was interrupted. Even if the Auxiliary supply is interrupted count will be maintained in internal memory. To reset No of Interruption manually see section Resetting Parameter 3.2.3.1

7. Negative sign indication

If the segment glows, it indicates negative sign of displayed parameter.



When Power factor lies in second and third quadrant, it has -ve sign, so active power has -ve sign as shown in the phaser diagram. Also in 3rd and 4th quadrant, reactive power is -ve. So the -ve annunciator glows to indicate the operation of system in respective mode as per the Phaser diagram shown on page 17. For example in the screen shown, Input values were 240V_{L-N}, 20A, and phase angle 187° hence the phase active power is displayed with -ve sign.