

SoMachine Basic Software Installation

System Requirements

To install SoMachine Basic the following computer specification is required:

- Windows 8/7/XP
 - 32bit or 64bit
 - Microsoft .NET version 4.0
 - 1GB RAM
 - 200MB Hard disk space
 - Dual core processor
-

Installation

SoMachine Basic installation comes as an executable file. Simply run the executable to install the software. The installer for SoMachine Basic will uninstall any previous version of SoMachine Basic before the installation.

If SoMachine Basic is updated to a newer version, the firmware in the M221 controller must also be updated.

For further details, see the installation guide located on the CD and firmware update in Chapter 2 - Firmware Update.