
Remove Text
Replace Text
Copy following configuration from one channel to other channel
Ignore Messages
Reports
Alarm Configuration
Alarm Configuration and Validation using Regular Expression
Finds Junk Characters and its ASCII code from DCS Alarmline
Block Configuration and Formatting
Production Report configuration in(TXT/XLSX)
Column Configuration and Formatting
Configuration of Voice /SIP calling parameters
Enable mailing of production Report
Verification of Configured Replace, Remove text and Ignore message configuration
X-Force Alarm Configurator
TriggerConfiguration (predefined condition on which notification will generates)
Sequence configuration to generate notification based on license
Pop-up configuration which displays on AIMS server only
Digital output through ADAM
Enable instant mailing
Mail group
SMS/Voice/SIP Configuration
Configure user's Phone number