# Step-1: Install OI Server PLC Driver



Open File - Security Warning

**We can't verify who created this file. Are you sure you want to run this file?**

Name:   ...$\UG\WW Training\OIServers\Setup-OI-ABCIP.msi

Type:   Windows Installer Package

From:   \\192.168.10.157\e$\UG\WW Training\OIServers\S...

[ Run ]   [ Cancel ]

This file is in a location outside your local network. Files from locations you don't recognize can harm your PC. Only run this file if you trust the location. What's the risk?

---

Wonderware Operations Integration - Supervisory Allen-Brad...

Wonderware Operations Integration - Supervisory Allen-Bradley ABCIP Server (G-1 Series) setup completed successfully.

[ Finish ]

Step-2: Open System Platform Management Console (SMC)

Step-3: Drill down list as shown below.



Step-4: Add Port





Step-5: Port Added.

## Step-6: Add PLC



## Step-7: Add IP of PLC in Node name.



## Step-8: Add topic (Right Click)



## Step-9: Topic Added

Step-10: Add PLC I/O addresses and Tagname as shown.



Step-10: Activate OI.ABCIP



Step-11: Save the Configuration